

## MS860 BlueTooth Scanner Quick Start

### Step 1.

Charge scanner for approximately five hours, until the battery led turns green



Step 2. Use a paper clip or pin to turn on the scanner itself




Step 3. Flip cradle over and set to appropriate communication method,

M5086

S/N: 1110259005


FC FCC ID: HLEM5086



This device complies with Part 15 of the FCC Rules.  
Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received,  
including interference that may cause undesired operation.



電波 92LP0326



Product of unitech

PAIR    SCM    RESET    3 2 1

Notice: When scanner LED is always ON,  
Please scan this bar code to reset the scanner.



Reset Scanner

Please follow the indication and turn the switch  
to the proper position for the interface connected:

- 1: USB
- 2: RS232
- 3: Keyboard Wedge

26 1:21 PM



Step 3. Scan the Serial number barcode on the bottom of the cradle with the MS860.



Step 4. Press the “pair” button on the cradle, look for the 10101 light to flash then turn off, the led on the top of the scanner should turn off.

